

Taal: Engels



Handleiding

Cav Tornado 11i - 15i

CA Tornado 11i

CA Tornado 15i

MSH equipment

Appelmarkt 7

1681 PE Zwaagdijk-Oost

Tel: 0228-561100

Fax: 0228-561112

Mail: info@msh-equipment.nl

Website: www.msh-equipment.nl



User's manual

Installation - Use - Maintenance



TURBINE EXHAUSTER TORNADO 11i - 15i



Tornado Manual	10-2007
Document	Revision





CONTENTS

1 GENERAL INFORMATION	3	5.4 OPERATING MODES	15
1.1 MANUFACTURER	3	5.5 JOB END	15
1.2 POINTS OF SALE AND SERVICE CENTRES	3	5.6 DECOMMISSIONING	15
1.3 CERTIFICATES	3	6 MAINTENANCE	15
1.4 WARRANTY	3	6.1 MACHINE CUT-OFF	15
1.5 CUSTOMER'S OBLIGATIONS	3	6.2 SPECIAL PRECAUTIONS	15
1.6 MANUAL LAYOUT	4	6.3 PARTS SUBJECT TO MAINTENANCE	16-17
1.6.1 PURPOSE AND CONTENTS	4	6.4 CLEANING	18
1.6.2 MANUAL ADDRESSEES	4	6.5 ROUTINE MAINTENANCE	18
1.6.3 MANUAL STORAGE	4	6.6 EXTRAORDINARY MAINTENANCE	18
1.6.4 SYMBOLS	4	7 DIAGNOSTICS	19
2 MACHINE DESCRIPTION (MACHINE)	5	7.1 TROUBLESHOOTING	19
2.1 PRINCIPLE OF OPERATION	5	7.2 AFTER-SALES SERVICE	20
2.2 MAIN COMPONENTS	5	8 SPARE PARTS	20
2.3 MACHINE STRUCTURE	5	8.1 SPARE PARTS LIST	20
2.4 DIMENSIONS	5	8.2 ORDERING SPARE PARTS	21
2.5 AMBIENT CONDITIONS	5	9 SCRAPPING	21
2.6 LIGHTING	5	9.1 DISPOSING OF WASTE	21
2.7 VIBRATIONS	5	9.2 MACHINE SCRAPPING	21
2.8 NOISE EMISSIONS	5	10 ANNEXES	21
2.9 SPECIFICATIONS	6	10.1 DECLARATIONS	21
2.10 OUTFIT	6	10.2 DIAGRAMS	21-29
2.10.1 STANDARD	6	10.3 WARRANTY FORM	30-31
2.10.2 OPTION EQUIPMENT ON REQUEST	6	10.4 MAINTENANCE LOG BOOK	32-33
2.11 ELECTROMAGNETIC ENVIRONMENT	6		
3 SAFETY RULES	7		
3.1 GENERAL WARNINGS	7		
3.2 INTENDED USE	7		
3.3 UNSUITABLE USE	7		
3.4 DANGEROUS AREAS	7		
3.5 SAFETY DEVICES	7		
3.6 STOP CONTROLS	8		
3.7 SAFE WORKING PROCEDURES	8		
3.8 RESIDUAL RISKS	8		
3.9 NAMEPLATES	8-9		
4 INSTALLATION	9		
4.1 TRANSPORT AND HANDLING	9		
4.2 STORAGE	9		
4.3 ARRANGEMENTS BEFORE INSTALLATION	9		
4.4 ASSEMBLY	10		
4.5 SET-UP	10		
4.6 CONNECTIONS	11		
4.6.1 PNEUMATIC CONNECTIONS	11		
4.6.2 ELECTRIC CONNECTIONS	12		
4.6.3 SUCTION	13		
4.6.3a OUTLET	13		
4.7 PRELIMINARY INSPECTION	13		
4.8 ADJUSTMENTS AND CHECKS	13		
5 OPERATION	14		
5.1 PERSONNEL	14		
5.2 CONTROL PANEL	14		
5.3 COMMISSIONING AND USE	14		



1 GENERAL INFORMATION

1.1 MANUFACTURER

CAV S.r.l., owner of the SMAI System trademark, has been manufacturing Service control units for industrial use for more than thirty years; this experience has led to a considerable technological Know-how based on many years of R&D activities carried out in tight connection with the product manufacturing and trading on the international market, and this is the best quality guarantee that SMAI System can offer to users.

1.2 POINTS OF SALE AND SERVICE CENTRES

SMAI System directly offers after-sales service for its products sold in Italy or in Europe.
(Sales, After-sales, Spare parts)

CAV S.r.l.,
Via Morandi, 90 - Toscanella di Dozza (Bologna), Italy
Postal Code 40060
Phone +39 (0)542 673488
E-mail: sales@cavitaly.com

Customers are kindly requested to contact the above-indicated central After-sales Service for any doubt or clarification about use, maintenance or request for spare parts. Please remember to specify the Machine identification details that can be found on the nameplates:
See Nameplate A, paragraph 3.9

1.3 CERTIFICATION

The Machine complies with the prevailing European Union Directives applicable at the moment of its release on the market, as detailed in the declaration of conformity.

1.4 WARRANTY

Machine components are covered by a 12-month (twelve month) Warranty: this period starts from the date indicated on the purchase document (invoice). **Warranty does not cover electrical and electronic parts.** Warranty only covers faulty parts, no labour costs and service call fee.
Warranty excludes any Exhauster damage due to:

- transport and/or handling;
- wrong or improper use of the Machine;
- failed compliance with maintenance specifications given in this Manual; (see paragraph 6.5)
- failures and/or faults not ascribable to faulty parts.

1.5 CUSTOMER'S OBLIGATIONS

The Customer shall, within the time frame agreed upon with the Manufacturer, fulfil its obligations indicated in the Documents attached to the sales contract. Unless otherwise agreed, the Customer normally shall take care of:

- Preparing the rooms, including any required building works and/or channels.
- Air supply with compressed air (see paragraph 4.6.1).
- Machine Power Supply, complying with the prevailing rules in the Country of use (see paragraph 4.6.2).



1.6 MANUAL LAYOUT

The Customer is required to carefully read this manual since correct pre-setting, installation and use of the Machine are basic requirements for its trouble-free and safe operation.

1.6. 1 PURPOSE AND CONTENTS

This manual shall give all necessary information for correct and safe use of the product. It deals with technical information, operation and maintenance details, as well as instructions for spare parts and safety warnings. Before attempting any operation on the Machine, Operators and Qualified technicians are required to carefully read the instructions given herein.

Manual content derives from an ongoing and methodical job of data processing and technical tests filed and approved by C.A.V., complying with the internal safety procedures and data quality rules.

Data herein indicated are **EXCLUSIVELY** for specialised personnel, that could interface with the product under safety conditions for any person, the machine and the environment, carry out a simple troubleshooting and understand strange/faulty operating conditions, carry out simple inspections and maintenance, still fully complying with the instructions given in the following pages and prevailing health and safety regulations.

All details about installation, assembly, removal, extraordinary maintenance, repair and installation procedures for any accessories, devices and equipment, are mentioned and can only be performed by specialised personnel or by the **AUTHORISED AFTER-SALES CENTRE**, fully complying with the manufacturer's recommendations and the prevailing health and safety rules.

It is important to keep this manual in a known place and ensure it is legible, for possible future reference. In case of damage or for further technical and operation details, please contact directly our **AUTHORISED AFTER-SALES SERVICE**.


1. 6. 2 MANUAL ADDRESSEES

This Manual addresses both the Operator and the Technicians allowed to carry out Maintenance operations on the Machine. Operators shall not carry out any operation reserved to Maintainers or Qualified Technicians. Failure to do so, the Manufacturer will not be liable for any resulting damage.

1.6.3 MANUAL STORAGE

This Manual shall be kept next to the Machine and in such a position protected from any fluid or any other condition that could compromise its readability.

1.6.4 SYMBOLS

	DANGER	Indicates a hazard resulting in a (serious) risk for user or any other person.
	WARNING	Pay utmost attention to the paragraphs highlighted by this symbol.
	DANGER OF ELECTROCUTION	Indicates a hazard of electrocution resulting in a (serious) risk for user or any other person.
	SPECIALISED PERSONNEL	Specialised personnel is required for special operations.
	SEE MANUAL	It is necessary to refer to the User's Manual before attempting a certain operation.
	ADJUST	Mechanical adjustment and/or electric set-up could be necessary.



2 MACHINE DESCRIPTION

2.1 PRINCIPLE OF OPERATION

This C.A.V. exhauster is made of a load bearing frame on which are installed mechanical, electromechanical, electronic and pneumatic devices or units that are used, altogether or combined with one another, for suction and filtering of the dust resulting from dry sanding primer or filler/surfacer.

The machine description specifies the intended use for which the product was designed, produced and protected. Any different use or failure to comply with the following specifications could create danger for persons and/or property.

The model described herein consists of some main and auxiliary units, whose functions are listed here below and are aimed at carrying out a production cycle under safety conditions.

Please exclusively contact directly the AUTHORISED SERVICE CENTRE for further details or specifications.

2.2 MAIN COMPONENTS

The machine consists of the following main components:

1. Operator control panel
2. Filter holder cylinder
3. Dust collector cylinder
4. Motor guard
5. Bedplate



2.3 EXHAUSTER STRUCTURE

Unit bedplate and main parts are made of a stiff metal structure. Separate filtering unit includes dust collection bin. Exhauster is completely enclosed by a metal front guard. A control panel with controls for operation and adjustment is installed on the side panel. The side panel is secured by means of some screws, remove it to gain access to the motor and its turbine.

Power supply connections are realised by means of power and control cables.

2.4 DIMENSIONS

Overall dimensions are specified under paragraph 2.9 -Specifications.

2.5 AMBIENT CONDITIONS

The Exhauster does not require any special ambient conditions. Nevertheless, it shall be installed in a well-lit industrial building, featuring suitable minimum guaranteed air change.

Ambient temperature for correct unit operation shall be in the range +5°C to +40° C.

2.6 LIGHTING

Room lighting shall comply with the prevailing rules in the country where the machine is installed. In the area where the Exhauster is installed, good visibility shall be ensured for easier routine and extraordinary maintenance. Minimum recommended illumination: 400 lux.

2.7 VIBRATIONS

If unit is used according to the instructions for correct use, vibrations shall not create any dangerous situation.

2.8 NOISE EMISSIONS

The Exhauster is designed and manufactured to limit noise emissions at the source.

Maximum noise emission is 80 dB. Actual noise emission shall in any case be measured after installation, in order to ensure that it still conforms to the specifications required by the prevailing laws.



2.9 SPECIFICATIONS

This section indicates Machine technical features and specifications user shall refer to in case of contact with the Manufacturer After-sales Service.

TABLE 2. 9A - Technical Features and Specifications

Description	Features
Power supply	400V-415V-50Hz
Installed power	Tornado 11i - 12.5 kW Tornado 15i - 18.5 kW
Compressed air supply	Max 10 Bar
Relative humidity	Max 90% w/out condensate
Weight (kg)	Tornado 11i - 370 kg Tornado 15i - 385 kg Filtering unit - 210 kg
Dimensions	Tornado 11i - 15i 1150x800x h1420 mm Filtering unit 1250x1120x h 2180 mm
Nominal power input	Tornado 11i - 28 A Tornado 15i - 37 A
Max. peak power input	Tornado 11i - 43.5 A Tornado 15i - 82.5 A

2.10 OUTFIT

The following equipment refers to the standard production Exhausters. Any special machine could hence require parts different than the listed ones.

2.10.1 STANDARD

The Exhauster comes with:

- User's Manual
- Declaration of conformity
- Fixtures for installation

2. 10.2 OPTION EQUIPMENT ON REQUEST

No options are set with respect to the standard outfit.

Any change and/or addition of any accessory whatsoever must be explicitly approved and made by the Manufacturer.

2. 11 ELECTROMAGNETIC ENVIRONMENT

The Exhauster is designed to operate correctly within an electromagnetic or industrial environment. Design conforms to the principles of the product Harmonised Technical Standards:

HARMONISED EUROPEAN STANDARD

EN 60439-1(third edition)

February (1995) ref. CENELEC EN 60439-1:1994-01

HARMONISED EUROPEAN STANDARD

EN 60439-1/AI/Ali September (1997) ref. CENELEC EN 60439-1/AI:1995-12+ EN 60439-1/Ali:1996-02

In particular, manufacturer used proven components and principles, as required by 7.10 of EN 60439-1/AI:1995-12+ EN 60439-1/Ali:1996-02

Built-in electronic equipment was installed as indicated in the instructions that come with the equipment itself and considering the general criteria for **EMC** specified in **EN 60204-1 art 4.**

HARMONISED EUROPEAN STANDARD EN 60439-1(third edition)

February (1995) ref. CENELEC EN 60439-1:1994-01

HARMONISED EUROPEAN STANDARD EN 60439-1/AI/Ali

September (1997) ref. CENELEC EN 60439-1/AI:1995-12+ EN 60439-1/Ali:1996-02

In particular, manufacturer used proven components and principles, as required by 7.10 of EN 60439-1/AI:1995-12+ EN 60439-1/Ali:1996-02



3 SAFETY RULES

3.1 GENERAL WARNINGS

The Operator shall carefully read the information given in this Manual, especially the Safety rules and precautions specified in this section.

Moreover, it is fundamental that the Operator follows these warnings:

- Keep the Tornado Exhauster and the work area clean and in order;
- Use the Exhauster in normal psychophysical conditions;
- Wear appropriate clothes and personal protection gear suitable for products in use;
- Do not remove or tamper with the Manufacturer nameplates on Exhauster;
- Do not remove or make inoperative any of the Exhauster Safety systems.
- **Do not use this unit in rooms subjected to risk of explosion.**

3.2 INTENDED USE

The Exhauster is designed for removing non-explosive dust in general or similar material.

3.3 UNSUITABLE USE

Do not use the Exhauster:

for different purposes than those indicated in 3.2;

- to take in substances that could result in a flammable and/or explosive environment;
- in environments featuring explosive, aggressive atmosphere or with high dust or oily content;
- in environments with a serious fire hazard;
- outdoors, exposed to any weather condition;
- to take in red-hot parts and/or parts on fire;
- in a different way than stated in safety installation rules given herein.

3.4 DANGEROUS AREAS

Although the Exhauster does not involve any particular danger for exposed persons, it shall be used taking some precautions, considering that:

- The operator can come into contact with dangerous chemical products by accident and without being aware of the resulting danger.
- Before use, the person in charge of production shall evaluate unit use conditions according to the danger possibly caused by products and take suitable protections such as: work in a room featuring a guaranteed minimum ventilation or change of air.
- **Pay utmost attention when removing the dust bag. Carefully follow the filter removal procedure described in the manual and shown in the figures on the package.**
- Exhaust tube and silencer could reach a very high temperature ($>55^{\circ}\text{C}$) so it is important that users wear any necessary safety gear before starting any operation.

3.5 SAFETY DEVICES

The Exhauster comes complete with suitable guards to protect the persons exposed to risks due to moving organs, risks connected to power supply, and so on.

The unit fits the following safety devices:

- Metal barrier all around the mobile parts or the ones under pressure. Basically, the enclosures are a barrier for any potentially dangerous parts.
- The emergency stop is controlled by the main switch on the electric board or by a **mushroom-head pushbutton** (option, provided by Customer).
- Rotating pushbutton cuts off machine supplies to perform maintenance under safety conditions.
- Safety release on the lever for removing the dust collector cylinder metal body.

The User is requested to install the following safety devices:

- Emergency knife switch, with differential protection of the B type for pulsating current and power input of 28A (Tornado 11i) or 37A (Tornado 15i), peak input of 43.5A and 82.5A for max. one minute, against direct and indirect contacts within the power control board of the Tornado Exhauster (if activated, it provokes uncontrolled stop of all actuators and power cut-out).



3.6 STOP CONTROLS

The Exhauster stop controls are:

- Main power cut-out by Main Switch (to set unit out of service; located on control board installed by the Customer);
- Emergency stop by means of external mushroom-head pushbutton (option);
- Rotating knife switch incorporated in **power control panel** that, when activated, cuts power to both auxiliary and power circuits;
- Controlled stop due to opening of the run enable auxiliary contact (e.g. suction mouthpiece Open / Closed).

3.7 SAFE WORKING PROCEDURES

The Exhauster design features aim at eliminating all risks connected to its use.

The residual risks involved in operating mode are:

- Risks connected with the use of pneumatic energy;
- Risks connected with the use of electric energy;
- Risks of possible contact with product removed by suction.
- Risks of possible contact with hot surfaces.

To limit the consequences of such dangers as much as possible, it is important to comply with the following rules:

- Ensure that air supply pressure is set to specified value: **max. 10 bars**;
- Do not start the Exhauster before checking the correct installation and parameters set at operator panel; this can be done by running a cycle with no product to be taken in by exhauster;
- Wear the personal protection gear suitable for the product in use;
- Wear close-fitting clothes.

3.8 RESIDUAL RISKS

During the normal suction cycle and during maintenance, the Operators can run some residual risks that can not be completely avoided, due to the type of operation being performed, such as danger of electrocution, noise and contact with hot surfaces (indicated by suitable warning plate).

3.9 NAMEPLATES

Table 3. 9A - Types of Nameplates

Nameplates on the Exhauster fig.3.9.A






Nameplate "A"	Nameplate "B"	Nameplate "C"	Nameplate "D"
			
			Nameplate "E"
			
			Nameplate "F"
			



Figure 3. 9 B - Nameplates position



	WARNING! THE SAFETY WARNING NAMEPLATES SHALL NOT BE REMOVED, COVERED OR DAMAGED.
---	--

4 INSTALLATION

4. 1 TRANSPORT AND HANDLING

Have unit transported by qualified and trained Personnel. The Exhauster shall be handled in a suitable way so as to avoid damages. All protections, electric circuits, control equipment, shall be suitably closed and fastened.

The Exhauster is packed on pallet, wrapped in plastic and covered with cardboard. Packed machine dimensions and weight are indicated on the package. Check for transport damages together with the carrier.

N.B.: The Manufacturer will not be liable for damages due to improper lifting and handling of the packed unit.

	WARRANTY does not cover any damage to the Exhauster due to Transport and Handling. Any repair or replacement of damaged parts is at the Customer's charge.
---	---

4. 2 STORAGE

For any long period of inactivity, store the Exhauster in a suitable place, considering storage environment and time. In particular, consider allowed temperature range, humidity and pollution.

- Store the Exhauster indoors;
- Protect the Exhauster from any shock and stress;
- Protect the Exhauster from humidity and extremely wide temperature ranges +0° C + 60 °C;
- Avoid contact with corrosive substances.

4.3 ARRANGEMENTS BEFORE INSTALLATION

Before installation, it is necessary to prepare a suitable operating area, limiting any interference with other activities as much as possible.



4.4 ASSEMBLY

Exhauster can be assembled either by the Technicians authorised by the manufacturer or directly by the customer, following these steps:

Unpacking.

Remove all packing material from the machine, using suitable tools and setting it in a suitable place. Dispose of the packing material according to the prevailing environment protection regulations.

(Visually) **check** machine external parts for damages, carefully ensure that there are no scratches, denting or damaged parts.

Report any fault, failure or missing parts found within five days from machine arrival. Beyond this term the Manufacturer is no longer liable for the machine supplied.

WARNINGS AND PRECAUTIONS for installation


Always start by checking correct operation, assembly and efficiency of controls and safety systems. **In case** you find operating faults, immediately stop the machine and contact the AUTHORISED AFTER-SALES SERVICE. **Pay attention** to the adhesive nameplates on the machine. Should they become damaged or illegible, promptly change them. For this operation contact the AUTHORISED AFTER-SALES SERVICE or the Manufacturer. Have **any maintenance intervention** -as per the definition of "user" given in the foreword section- performed by qualified personnel. **Using spare parts** that do not comply with the following specifications, any change or tampering (though small as they may be) relieve the Manufacturer of any liability concerning the correct use, operation and safety of persons and/or property. **It is strictly forbidden** to tamper with equipment, control organs and safety devices. **Dispose of waste** as required by the prevailing laws. **If the machine is used by many operators**, all of them shall read the instructions for use and indicate any maintenance intervention or parts replaced, or just suspected faults on the servicing data sheet.


4.5 MACHINE SET-UP

Set Exhauster and filtering unit on a flat and clean surface and ensure that the equipment and tools for machine mechanical set-up are in place.

To handle the machine under safety conditions, lift it by means of a fork lift truck. After setting the machine in position, level it and tighten the lock nuts to ensure it stays firmly in place.

N.B.: It shall always be possible to work all around the machine for maintenance purposes. Ensure there is enough room in this area upon installation.





4.6 CONNECTIONS

To avoid any problem at Exhauster start-up, follow the instructions below.

4.6.1 PNEUMATIC CONNECTIONS

Figure 4. 6. 1A- Pneumatic System Layout

Connection to the air supply is ensured by a flexible hose secured with screw clamps.

The mobile connection is supplied together with the Exhauster.


The standard Exhauster comes with regulator unit.

Air supply requirements:

- Operating pressure: 5 bars
- Maximum pressure: 10 bars

Connect compressed air supply to the supplied line by inserting a gate valve (to be supplied by Customer) on the pre-set line so that the supply can be cut off during maintenance. It is strongly recommended to feed the machine with dry compressed air.

Compressed air of the supply line must be completely dry, i.e. treated upstream of the exhauster. It is recommended to install a 5 micron air filter.





4.6.2 ELECTRIC CONNECTIONS

Figure 4. 6. 3A- Electric System Layout

POWER SUPPLY

Exhauster electrical connections are at the Customer's charge, under its own responsibility.


The electrical connections of the Exhauster shall consider:

The Laws and Technical standards applicable at the time of installation in the place of installation;
Data indicated on " Nameplate A ".

Make the electrical connections. Supply power to the machine with a separate line of suitable cross-section, also providing suitable protections for direct and indirect contact. **This line and the relevant protections are at the Customer's charge.**

- Power cord is with double insulation and of suitable cross-section (approx. 3m) and completed with ground wire.
- Control cable or for remote starting shall have a section of 2x1.5 sq.mm (approx. 3m) and shall be connected to electric item microswitch line.
- Feedback shielded cable for connection of the vacuum sensor, completed with suitable connector (approx. 100m). The sensor shall be set in a position as close as possible to the area mostly used, or in the point agreed at the design stage.

The electrical system design and components ensure utmost dependability and safety of use. The attached wiring diagrams will allow identification of all connections and components. Only make the required electrical connections; do not modify any circuits, calibrations, components, etc. Failure to follow this warning will be considered as tampering. Before connecting to the mains, ensure that power voltage and frequency correspond to the specifications indicated on the nameplate. Perform ground connections and/or zero setting as required by the local power supply firm.





4.6.3 SUCTION

After positioning exhauster and filtering unit, connect them using the supplied Ø100 hose (A)

When finished, connect the Ø100mm fitting (B) located on dust inlet cylinder to an antistatic flexible hose deriving from the main suction line. Fasten the hose with its metal clamp.

4.6.3a OUTLET

Install silencer (C) on outlet manifold and secure it with the supplied metal clamp. Set outlet lines having a minimum diameter of 100 mm. It is necessary to install, in-between silencer and outlet line, a rubber hose to allow for silencer removal and maintenance.

4.7 PRELIMINARY INSPECTION

Power supply, compressed air supply and Exhauster preparation stages for Commissioning do not require any special knowledge apart from those acquired after reading this manual.

Before starting up the Machine it is necessary to perform some inspections and checks in order to avoid errors or accidents:

- Ensure that the Exhauster did not suffer any damage during assembly;
- Pay special attention when checking electrical parts, control panels, cables and air lines;
- Check that all external supplies connections are correct;
- Ensure that all mobile parts can move freely.

4.8 ADJUSTMENTS AND CHECKS

The Exhauster is tested at the Manufacturer's premises, before shipment. No further adjustment is necessary.

When starting the Exhauster for the first time, proceed as follows:

- Set the Main switch QSI lever to ON (**switch is installed by the Customer**);
- Open compressed air supply cock; ensure that compressed air regulator reads 5 bars;
- After being supplied, the Exhauster sets to automatic operation mode. Only by voluntarily activating the control "I" can the machine be set to stand-by mode, ready to start when the remote starter contact is closed.





5 OPERATION

5.1 PERSONNEL

The Exhauster is designed for use by many Operators.

Personnel allowed to work on the Exhauster shall have the following knowledge (or acquire it after suitable training) and be familiar with the contents of this Manual as well as all Safety-related concerns:

- General and technical knowledge of suitable level to understand Manual contents;
- Knowledge of the main health and safety and accident prevention rules;
- Know how to behave in an emergency situation, where to find personal protection gear and how to use it correctly.

Maintainers, apart from the above, shall also have suitable electrical, pneumatic and mechanical Technical knowledge.

5.2 CONTROL PANEL

Exhauster controls are on the control panel, at Machine front.

Figure 5.2 a - controls on front panel

KEY:

- Pushbutton "I" sets the machine ready to start suction operations;
- Pushbutton "O" sets the machine off;
- Pushbuttons Y1,Y2,Y3 allow for filter cartridge manual cleaning;
- Reset pushbutton allows for inverter restarting after a fault condition;
- Inverter interface panel allows user to set inverter parameters and display of error codes.



5.3 COMMISSIONING AND USE

To power on the Exhauster proceed as follows:

1. set Main switch to ON
2. Open compressed air supply cock
3. Press pushbutton " I " to set the machine to Stand-By mode;
4. When one of the suction mouthpieces opens, so that the remote contact closes, the machine starts and performs set function, as **pre-programmed at the Factory with default settings**, that are usually suitable for normal use. If generated vacuum is not suitable to the production needs, user can change parameter C0181 and vary it. Changes made to this parameter are proportional to vacuum variation that can be obtained. When C0181 value increases, even the machine power consumption increases while the machine range for use decreases.
5. Following are the instructions for reading/editing inverter parameters.





Step	Pushbuttons	Result	Action
1	Display switch-on	Disp XX.XX Hz	The function Disp is active. C0050 value is displayed.
2	Parameter setting / reading	Code	Select the "Code" function.
3		XXXX	Select the function code.
4		Para	Select the "Para" function.
5		XXXX	Set the desired value for the parameter.
6	ENTER	STO-E	Confirm selection while is flashing
			Confirm selection while is not flashing
7			Go back to step 2 to set more parameters.

5.4 OPERATING MODES

After commissioning you can use the machine, no operator intervention is necessary.

5.5 JOB END

The procedure for a voluntary Stop is as follows:

1. Open the main switch on electric panel installed by the customer (OFF position);
2. Close compressed air supply cock.

5.6 DECOMMISSIONING

In case of long periods of inactivity or **in case of maintenance, user shall compulsorily:**

- Open and padlock the main switch QSI on main control panel (see Figure 6.1 A);
- Close and lock compressed air inlet valve (see Figure 6.1 B);
- Release circuit air by opening the condensate drain cock;
- Put out a panel reading "EXHAUSTER BEING SERVICED".


6 MAINTENANCE

6.1 EXHAUSTER CUT-OFF


Before attempting any Maintenance or Repair job, user must cut all Exhauster supplies, proceeding as follows:

1. Open and padlock the main switch on main control panel (6.1A).
2. Close and padlock the compressed air supply and open the condensate drain cock to drain the system (6.1B).

6.1A



6.1B



6.2 SPECIAL PRECAUTIONS

When carrying out Maintenance or Repair jobs, it is recommended to proceed as follows:

- Before starting, put out a panel reading "EXHAUSTER BEING SERVICED" in a visible position.
- Do not use solvents and flammable materials;
- Do not release lubricants into the environment;
- Machine parts are not designed to bear a Person's weight; do not stand on them or they could break.
- When job is completed, restore and correctly fasten all protections and guards previously removed or opened, as well as any safety device, if previously disabled.



6.3 PARTS SUBJECT TO ROUTINE MAINTENANCE

Maintenance shall be carried out with the Exhauster set out of service for replacement of damaged or worn parts. The Exhauster does not require frequent maintenance. If compressed air does not meet indicated requirements, the following could get damaged:

1. Pressure regulator
2. Solenoid valve
3. Filter cartridge
4. Dedusting device

Should cartridge fail and break, this could damage the turbine unit (5) and the silencer (6).

1) Remove the regulator:

- Close air feed;
- Release any residual air by opening the condensate drain cock;
- Disconnect the lines, loosen the regulator to release it from the support;
- Remove the regulator following this sequence:
 - Turn adjuster knob counter clockwise until releasing it;
 - Push knob into body until releasing it;
 - Turn knob counter clockwise;
 - Clean/change the membrane.
- Refit the regulator;
- Restore 5 bar pressure.



2) Replace solenoid valve if it jams. Change as follows:

- Close air feed;
- Release any residual air by opening the condensate drain cock;
- Remove the connecting tubes and loosen the solenoid valve;
- Clean and/or change the solenoid valve;
- Reconnect the tubes.





3) Filter cartridge

- Cut off power and air supply (see relevant procedures in the previous pages);
- Disconnect Ø100 inlet hose from inlet manifold;
- Remove dust collector cylinder detaching it from the hopper and place it on its wheels;
- Loosen nut under cartridge;
- Set the new cartridge in place, ensuring to set it at the centre and that the seal correctly sets against the plate;
- Tighten the nut, do not squeeze seal too much (nut finger tight + two turns);
- Refit the dust collector cylinder and hook up the four hooks;
- Reconnect the Ø100 hose.

4) Dedusting device



- Cut off power and air supply (see relevant procedures in the previous pages);
- Proceed as described in step 4 until removing the filtering cartridge;
- Loosen the dedusting device and renew it;
- Reassemble as indicated in item 5.

5) Motor

- **Cut off power** and air supply (see relevant procedures in the previous pages);
- Contact Authorised Service Centre.

6) Silencer

- **Cut off power** (see relevant procedures in the previous pages);
- Remove the silencer unit, **ensuring no foreign objects can fall inside the turbine outlet tube;**
- Blow compressed air at 6 bars inside the silencer;
- Reassemble the silencer unit.





6.4 CLEANING

It is recommended to frequently clean the whole Machine (intervals depend on type and frequency of use). Use a soft rag. Do not use water and/or solvents.

- **Monthly** clean inside the machine to ensure motor and inverter cooling efficiency.
- **Changing the bag.** It is impossible to set a standard interval for replacing the dust collector bag so it is important to frequently check dust quantity during the first two weeks of use. Periodically empty the bag according to the work you do. Release the three levers to unlock the dust collector cylinder. Disconnect the vacuum tube and remove the cylinder by pulling the two side handles. Pull out the nylon bag and close it. Fit a new bag, ensure it adheres to cylinder walls. Turn over bag exceeding length on cylinder edge. Refit the dust collector cylinder and engage the three levers. **Important!** Refit and ensure that the vacuum tube does not leak. Any leak (though small as it may be) will move the nylon bag up toward the filter cartridge, thus blocking off the machine suction opening, and finally break the bag. It is necessary to dispose of the collected dust according to the prevailing laws of the country where machine is installed.



6.5 ROUTINE MAINTENANCE

The following operations shall be performed at the indicated time intervals. Failure to comply with this schedule will relieve the Manufacturer of any liability or Warranty obligation.

These operations, though simple as they may be, shall be carried out by **suitably trained and expert Personnel**.

Scheduled routine Maintenance includes inspections, tests and interventions aiming at preventing system stoppage due to faults or potentially dangerous situations.

6.6 EXTRAORDINARY MAINTENANCE

Extraordinary maintenance is an activity reserved to personnel appointed by the manufacturer or the manufacturer itself. Please contact the centres specified under paragraph 1.2 in case of need. **Considering the machine routine maintenance, the intervention of a technician for extraordinary maintenance is highly unlikely, unless for special cases or when expressly requested.**

MAINTENANCE	DESCRIPTION	INTERVENTION
Pneumatic System	Valves and tubes/lines	No scheduled maintenance required.
Electrical System	Control Panel	No scheduled maintenance required.
Suction System	Filter	Change every 2000 hours.
Turbine Motor	Bearings. Have bearings changed by an Authorised Service Centre.	Change every 15,000 hours.
Motor compartment and cooling fans	Clean carefully.	Monthly.
Dust collector bags	Change.	When necessary.
Inverter and electrical parts	Control panel internal parts	Maintenance-free. If the inverters are faulty, have them changed by qualified personnel.




Tighten power wiring screws	Tighten screws and junctions PLACE UNIT OUT OF SERVICE BEFORE PERFORMING THIS OPERATION	Perform 3 months after installation and repeat every six months.
-----------------------------	---	--

7 DIAGNOSTICS

7.1 TROUBLESHOOTING

Table 7.1 A

TROUBLE	CAUSE	INSPECTION AND/OR FIX
Dust is coming out of the silencer.	- Faulty filter cartridge - Worn seal	- Change filter cartridge - Change filter cartridge
The solenoid valve or regulator "hiss"	- Poor air quality, dirty membranes - Membrane failure	- Install air filter at inlet - Clean/change regulator/solenoid valve
The motor is not starting	- No power supply from the mains - The machine is not set to stand-by mode - The inverter is in blocked state	- Check power supply. - Press pushbutton "1" to enable inverter start - Find (alphanumeric) error code and check against inverter errors chart on page 20
The motor stops	- No power supply from the mains - The inverter is in blocked state - Inverter/motor overload	- Check power supply. - Find (alphanumeric) error code and check against inverter errors chart on page 20 - Check machine cooling fan for dirt; check dedusting device and filter cartridge operation.
Filter is not automatically cleaned	- No compressed air feed. - Dedusting device is stuck - Faulty timer - Faulty solenoid valve	- Restore compressed air feed. - Clean/change dedusting device - Change timer - Clean/change the solenoid valve
Faulty or insufficient suction	- Filter clogged due to failure of emptying dust collector bag - Damp filter - Suction of objects - Dedusting device is stuck - Faulty solenoid valve - Faulty timer - No compressed air feed.	- Empty dust collector bag more frequently, an excessive quantity of accumulated dust clogs the filter cartridge - Check for condensate in the machine accumulation tank. Install a filter at machine inlet - Check for the correct suction value, disconnect tube diam.100 from filter holder cylinder. If suction is correct, system took in something that jams air passage in tube. Remove jamming. - See above - See above - See above - See above
The motor is always running at max. rpm	Vacuum sensor faulty/disconnected	Reconnect the vacuum sensor and/or change the sensor.



ERROR CODE	DESCRIPTION	CAUSE	REMEDY
OC1	Short-circuit	Motor/power cables short-circuit	Check power cables and motor
OC2	Discharges toward ground	One motor phase is grounded	Check power cables and motor
OH	Inverter heat sink overheat	Failed or poor inverter cooling	- Clean inverter cooling fan filter - Blow inverter heat sink with compressed air to clean - Check inverter cooling fans operation
OH3	Motor overheat	- Frequent start/stop operations - PTC failure "Dirty" motor	- Decrease the number of start/stop operations - Contact the Service Centre - Open motor case and clean the motor. Excessive dirt adversely affects motor cooling.
OH4	Inverter overheat	Failed or poor inverter cooling	- Clean inverter cooling fan filter - Blow inverter heat sink with compressed air to clean - Check inverter cooling fans operation
If any other error code is displayed, please take note and contact the Service Centre			

7.2 AFTER-SALES SERVICE

The Manufacturer is always willing to answer Customer's questions and give information on use, maintenance or installation and so on. Please follow the instructions given under paragraph 1.2 on how to request our assistance.

8 SPARE PARTS

8.1 SPARE PARTS LIST

Exhauster use does involve some expendable parts. Following is the list of available spare parts and expendable parts.

Table 8.1- A

POS.	DESCRIPTION	PART NO.
1	Side-channel blower	Tornado 11i: SK11-I-S-0001 Tornado 15i: SK15-I-S-0001
2	Solenoid valve	9018
3	Pressure regulator	6709
4	Pressure gauge	K2-78
5	Silencer	SIL-6
6	Dedusting device	K5-0080
7	Filter cartridge	K5-38-C-POLY
8	Top seal	7867
9	Vacuum tube	TA-29-040
10	Vacuum tube fittings	6468+6469+M92
11	Bottom seal	7867



POS.	DESCRIPTION	PART NO.
13	Cooling fan	
14	Dust collection bag	99987

8.2 ORDERING SPARE PARTS

We remind you that the Machine can only be repaired by a Qualified Technician.

It is hence recommended to contact the Manufacturer After-sales Service that will make available Qualified Personnel, suitable equipment and original spare parts.

To order above-listed spare parts, please refer to paragraph 1. 2

9 SCRAPPING

9.1 DISPOSING OF WASTE

During processing, waste or rejections are created that shall be collected, recycled or disposed of, in compliance with the prevailing laws of the country where the Machine is installed.

9.2 MACHINE SCRAPPING

Upon unit scrapping, separate the plastic parts from any electrical components, that shall be sent to different waste disposal centres, as per prevailing rules.

The Machine metal parts shall be divided into steel and other metals or alloys, and then routed to recycling firms.

Unit scrapping does not cause any special risk, as far as it is performed by qualified personnel with suitable equipment.

10 ANNEXES

10.1 DECLARATIONS

The following Declarations are hereby attached:


- Declaration of conformity to Directives 98/37/EC (former 89/392/EEC), 89/336/EEC and 73/23/EEC.


10.2 DIAGRAMS


The following Diagrams are hereby attached:


- Electric circuit diagram and key;
- Pneumatic circuit diagram;
- Machine exploded view.


Electric circuit diagram















List of components - control electric panel			
ID	Description	Manufacturer - Specs	Part no.
Q1	Main switch	Telemecanique	Tornado 11i: V3-63A Tornado 15i: V4-80A
F1	Motor fuses	Elettritalia	Tornado 11i: 22x58 - 63A Tornado 15i: 22x58 - 80A
F3	Fan fuses	Elettritalia	10x38 - 10A
F4	Auxiliary fuses	Elettritalia	10x38 - 2A
F5	Auxiliary fuses	Elettritalia	10x38 - 8A
F6	Auxiliary fuses	Elettritalia	10x38 - 4A
TR1	Transformer	CE	200VA 400/220/24V
U1	Inverter	Gardner Denver	Tornado 11i: SK11-I-S-0011 Tornado 15i: SK15-I-S-0011
FL	Filter	Gardner Denver	Tornado 11i: SK11-I-S-0013 Tornado 15i: SK15-I-S-0013
H11	Hour counter	Iskra	HK6-24V
U2	Timer	CAV	9162
S4	Reset pushbutton	Moller	M22-D-B/M22A/M22K10
S7	Stop pushbutton	Moller	M22DDLWSX1/X10
S6	Start pushbutton	Moller	M22DDLWSX1/X10
S5	Emergency stop pushbutton	Moller	M22PV/M22A/M22K01
S1-H7	EV1 pushbutton	Moller	M22-DL-G
S2-H8	EV2 pushbutton	Moller	M22-DL-G
S3-H10	EV3 pushbutton	Moller	M22-DL-G
K1	Contactor	Moller	Tornado 11i: DILM25-24V Tornado 15i: DILM32-24V
K2	Contactor	Moller	DILM9-24V
FR2	Thermal cutout	Moller	Z00-04/0.24-0.4A
TER	Thermostat	ETA	W1284-1140
Fan	Control panel cooling fan	Suntronix	SJ1238HA1
KR1 KR2 KR3	Auxiliary relay	Omron	MY4-24VAC
H1	Line lamp	Moller	M22-LC-W
H4	Cooling fan lamp	Moller	M22-LC-G
H5	Thermal cutout lamp	Moller	M22-LC-R
H6	Run lamp	Moller	M22DDLWSX1/X10
H9	Inverter shutdown lamp	Moller	M22-LC-R
D1	Timer	Omron	H3DE-S1-24V
SM1	External start microswitch		
S5E	External emergency		



Pneumatic circuit diagram





Please see descriptions in Table 8.1-A, page 20